



+ [View More](#)

PRODUCT NUMBER: 6551500
**BACOU TPT WHITE LABO SB
EA SRC**

Overview

Reference Number
6551500

Product Type
Footwear

Range
White

Brand
Sperian

Brand formerly known as
BACOU

Industry

- Medical and Pharmaceutical
- Food Industries
- Laboratory

Product Use
Safety shoes for professional use

Features & Benefits

Feature

PU wedged outsole

Benefit

Flexible and light Slip resistance on different types of surfaces

Feature

200J safety toecap

Benefit

Offers optimal protection

Feature

Half leather insole

Benefit

Comfort and durability

Feature

White perforated leather upper

Benefit

Aeration of the foot for added comfort

Technical Description

Sizes

35-42

Table Size

Table Size

Upper

Top-grain leather thickness 1,6-1,8 mm perforated for aeration. Leather-lined forefoot High upper with comfortable padded cushion. Entirely white.

Toe Cap

Protective epoxy treated steel

Insole

Leather insole

Outsole

Built up heel. Polyurethane mono density :PU 1D Excellent anti-skid properties Adherence coefficient: SRC, according to EN ISO 20345: 2004/Am.1: 2007 Very good abrasion resistance Good resistance to flexion Good resistance to rupture Good resistance to heat < 100° Energy Absorption Capacity > 20 Joules

Certifications

E.C. Declaration of Conformity


EC Category PPE

2

Quality Assurance

ISO 9001 / 2008

EC Attestation

 EC Attestation

EC Attestation Number

0075/826/161/04/08/0118

Photos & Images

We're sorry, there are no images available at this time.

Maintenance

Life Cycle

If the footwear is supplied with a part of, or the whole sole unit made of polyurethane:

We advise that the footwear should be used in the limit of 3 years following the manufacturing date, which figures on the footwear.

After this time limit, certain factors such as : exposure to sunlight, hydrometry, temperature changes, could cause a modification in the structure of the material, which would no longer maintain the same performance levels with regards to the requirements defined in the European Directive 89.686 CEE.

If the footwear is supplied with a sole unit made from a material other than polyurethane:

We advise that the footwear should be used in the limit of 5 years following the manufacturing date, which figures on the footwear.

Storage Information

Footwear should be stored in their original packaging, kept in a controlled stock area, not subject to rapid changes in temperature or humidity levels.

Care Instructions

After use leave your footwear to dry in an aired place away from heat.

Remove any excess dust or dirt with a brush. Remove any marks using a damp cloth and soap if necessary.

Finally polish any grain or pigmented leathers using a commercially available shoe care product.

Honeywell

[View other region sites](#)

© 2013 Honeywell International Inc.

|